

## PROTOCOL FOR USE

### HOW TO USE THIS APPLIANCE



WARNING! THIS PROTOCOL DOES NOT REPLACE THE INSTRUCTIONS AND WARNINGS CONTAINED IN THE USER MANUAL AND ON THE APPLIANCE: PLEASE READ THEM BEFORE USE.

- Before starting the treatment, clean - if necessary - the surfaces and fabrics with the most appropriate method for removing dirt and dust.
- If your appliance is equipped with steam adjustment - as it can also be used as a steam cleaner - set it to an average level or, in the presence of preset programs, refer to the instruction manual.
- Heating the dispenser: when the appliance is first switched on, dispense “unusable” steam for about 30 seconds downwards to reach the optimum operating temperature and pressure. After each pause before treating surfaces or fabrics, dispense for a few seconds in the same way.

### CHOOSE THE OPERATION YOU WANT TO DO:

#### DEEP DISINFECTION<sup>1</sup>

Objects and surfaces more exposed to frequent and continuous contact (e.g. handles, counters, taps ...)

Dispense steam perpendicular to the surface keeping a maximum **distance of 10 centimetres** (spacer stand) for **30 consecutive seconds**. The steam will be able to treat an area with a diameter of about 10 cm.



#### FREQUENT SANITIZING ACTION

Dispense steam with slow and repeated strokes from right to left (or vice versa), or from top to bottom (or vice versa) at about **10 centimetres per second**.



Refer to the table below for the treatment of different surfaces and fabrics. The table indicates, depending on the treatment to be carried out: the use of the stand spacer open (distance 10 cm) or closed (close distance); the use or not of the concentrator accessory (straight or curved); with HPMed or an empty bottle inserted.

		STAND / SPACER	CONCENTRATOR ACCESSORY	HPMED
<b>HARD SURFACES</b> (including glass)		✓	-	✓
<b>UPHOLSTERY</b> (cushions, upholstered chairs, armchairs, mattresses ...)		-	-	✓
<b>FABRICS / CLOTHING<sup>2</sup></b>		-	-	✓
<b>ELECTRICAL APPLIANCES<sup>3</sup></b>		✓	-	✓
<b>DRAINS AND GRILLES</b>		-	STRAIGHT	USE EMPTY BOTTLE
<b>TOILETS / INACCESSIBLE AREAS</b>		-	CURVED	USE EMPTY BOTTLE

After treatment, wait for the rapid and spontaneous drying of surfaces/fabrics. Drying times depend on the environmental conditions (temperature and humidity), on correct use and on the nature and temperature of the surfaces. Complete drying with a disposable cloth **only if** absolutely necessary.





**HPMED IS AN ADJUVANT DETERGENT FOR THE SANITIZING ACTION OF STEAM.**

- › It is respectful of the environment
- › It can be used in the presence of people and animals
- › It eliminates odours
- › It can be used on surfaces and fabrics without damaging them

<sup>1</sup> Tests and/or studies by third party and independent laboratories attest that Polti Sani System kills up to 99.999% of viruses, germs, bacteria, fungi and spores. For more information visit the website [www.poltisanisystem.co.uk](http://www.poltisanisystem.co.uk)

<sup>2</sup> For fabrics that may be particularly sensitive to heat, avoid concentrating the steam on a fixed point and instead sanitise it with repeated passes. Treat waterproof fabrics as hard surfaces.

<sup>3</sup> For electrical appliances, remove the plug from the socket before carrying out any operation and wait for the surfaces to dry perfectly.